



Centrotherm

InnoFlue®

Installation Instructions for the 3" & 4" B-Vent Kit

IFBK03/IFBK04

FLEXIBLE

Contents of the Kit	Installation Instructions		
		<ol style="list-style-type: none"> <li data-bbox="831 267 1617 397"> <p>Mount metal bracket of Base Support between floor joists and below B-Vent.</p> <li data-bbox="831 397 1617 657"> <p>Cut the 3" or 4" Flex (at the bottom of a male part) at the length of the B-Vent plus 2ft. Attach spacers to 3" or 4" Flex every 6.5 ft. Pull 3" or 4" Pipe through the B-Vent, inserting male to Base Support. Snap on Connector Ring to ensure connection.</p> <li data-bbox="831 657 1249 966"> <p>Slide B-Vent Cap (Part A over 3" or 4" Flex and use three 1/2" screws provided to fasten B-Vent Cap to B-Vent in appropriate recessed step.</p> <li data-bbox="1249 657 1617 966"> <p>Slip the Locking Ring over the 3" or 4" Flex.</p> <li data-bbox="831 966 1617 1144"> <p>Trim 3" or 4" Flex flush with Locking Ring.</p> <li data-bbox="831 1144 1617 1356"> <p>Connect Flex End Pipe into Locking Ring.</p> <p>Push Universal B-Vent Cap (Part B) over End Pipe and fasten at triangle tips using 3 of the 1/2" screws provided.</p> <li data-bbox="831 1356 1617 1502"> <p>From Base Support, make the connection to the appliance with rigid components, following Horizontal Installation instructions.</p> <p>Refer to approved appliance matrix for appropriate appliance adaptor: www.centrotherm.us.com/literature/o-e-m-approvals/</p> 	